




*Air Doors*  
BRAND AIR CURTAIN

14716 S. BROADWAY, GARDENA, CA 90248 • TEL: (310) 532-1555 • FAX: (310) 324-3030

# ELECTRICAL INSTALLATION INSTRUCTIONS

## AIR CURTAIN



### TYPICAL INSTALLATION

1. CONNECT SUPPLY VOLTAGE FROM POWER PANEL TO CONTROL PANEL.
2. CONNECT WIRES FROM MOTOR LEADS IN JUNCTION BOX(S) TO TERMINALS IN PANEL PER PRINT.
3. CONNECT WIRES FROM MICRO SWITCH TO TERMINALS IN PANEL PER PRINT.
4. CHECK ROTATION OF MOTORS AND SWITCH LEADS IF NECESSARY. (3 PHASE ONLY)

NOTE: 1) CIRCUIT PROTECTION AS PER NEC BY OTHERS.  
2) OVERLOADS ARE FACTORY PRESET.